

Results **USB Normal Mode** (all values in ms)

Used USB-Remote: "CanoRemote" - view:

<http://www.canoremote.de/index.html>

(English) or

http://www.canoremote.de/CanoRemote_de.html

(German)

Powershot SX20 (with Digic-4)

Test with: **German CHDK version 1.3.0 3429**

Key:	Default	1	2	3	4	5	6	7	8	9	10	Max. to short	Max. to long
Left	80	60	70	70	60	70	80	60	70	70	70	-20	n/a
Right	160	150	130	160	150	130	140	140	150	140	150	-30	n/a
Up	240	230	210	220	240	210	200	230	210	220	210	-40	n/a
Down	320	280	260	280	290	280	290	280	290	290	290	-60	n/a
Play/Pause	400	360	340	370	350	360	350	370	380	340	380	-60	n/a
Menu	480	450	420	450	450	420	430	440	440	430	430	-60	n/a

Powershot S3 (with Digic-2)

Test with: **German CHDK version 1.3.0 3437**

Key:	Default	1	2	3	4	5	6	7	8	9	10	Max. to short	Max. to long
Left	80	50	50	50	40	40	40	50	50	40	40	-40	n/a
Right	160	90	80	110	80	70	80	100	80	100	80	-90	n/a
Up	240	140	130	120	140	150	130	120	130	140	130	-120	n/a
Down	320	180	170	160	170	170	160	170	170	180	170	-160	n/a
Play/Pause	400	210	220	200	190	200	200	200	200	220	210	-210	n/a
Menu	480	250	250	250	250	250	240	250	250	250	250	-240	n/a